



CONTROLS




Power button:
- Power ON and OFF the system.




Plus-Minus keys (right edge of the base):
- Adjust zoom level.



Read button:
- Quick press:
Start reading a document.
- Long press:
Save a document.



Touchpad:
- Perform touch gestures here.



Back button:
- Quick press:
Return to previous screen.
- Long press:
Access the Quick Settings.

GESTURES



TAP

Press your finger down quickly at any location on the touchpad.



SWIPE


Swipe forward (to the left) or back (to the right) by sliding and releasing your finger.



PAN


Slowly move your finger in any direction without lifting it.

Diamond Edge / Contrast



Toggle between color, positive, negative, and Diamond Edge™ contrasts by swiping on the right edge of the touchpad.

Read Mode / Live Mode



Toggle between Read and Live views by swiping on the left edge of the touchpad.

North America: 1 (800) 722-3393

Europe: (0044) 1933 415 800


Australia/Asia: (02) 9686 2600

Customer Support: humanware.com/prodigi_support

USING PRODIGI



Place your document in the page-size frame and remove your hands from the viewing zone.




Move the locator by panning to quickly reach a section of the document you want to read.



Tap to enlarge the section defined by the locator.



When a section of a document is magnified, pan to reach other parts of the document.



Use the Plus-Minus keys to adjust the zoom level.



- Press quickly on the Read button to start reading a document, to pause, and to resume.
- Press and hold the Read button to save a document.



- Press quickly on the Back button to stop reading and go back to the previous screen.
- Press and hold the Back button to access the Quick Settings.

For more information contact us today.

Indigo Logix, LLC

sales@indigologix.com

615-822-3465